

SunStamp



*For the Effect of
stamped
concrete*

DESCRIPTION

SunStamp is the versatile, custom designed stamped overlay that combines “Old World” elegance with today’s technology.

SunStamp and its union of stamps, templates, freeform carving and coloring techniques makes a lasting impression on any concrete project. SunStamp is only installed by authorized SUNDEK artisans.



Sundek Products Needed

- **Sundek Additive**
- **Sundek Premix**
- **Sundek Overlay**
- **Lift off release**
- **SunStain**
- **Sundek Crystal Clear**

Product Description

Sundek Additive – A low solids acrylic binding polymer.

Sundek Premix – An acrylic base cement with medium grade sand.

Sundek Overlay – An acrylic base cement with large grit sand.

Lift off release – An oil base de-bonding agent

SunH2O – A water base acrylic stain

Sundek Crystal Clear – A one part urethane solvent base sealer (30% solids)

Application Instructions

Clean and etch concrete with a floor machine. Surface may also be diamond ground followed by pressure washing. Squeegee excess water and allow drying until there are no visible signs of water. Slab and ambient temperature above 40 ° and rising, staying above for at least 4 hours. Apply a primer if needed. Perform all necessary repairs and install Sundek base coat; a second coat may be applied if required by substrate conditions. Detail and sand to smooth out base coat surface, and then apply SunStamp overlay to surface. While SunStamp surface is still fresh, apply Lift off release to surface and stamping mats, then proceed to stamp. Once dry, detail and lightly sand surface to remove any burrs or imperfections preparing it for SunH2O application. Spray SunH2O through out entire surface. After the SunH2O is completely dry, apply Sundek Crystal Clear coat for surface protection.