

CLASSIC TEXTURE



*The Acrylic
Spray Texture
System That
Started It All in
1970.*

DESCRIPTION

The Sundeak Classic Texture is the decorative concrete application that helped launch an industry. If you've ever walked across a textured pool deck in your lifetime and it was comfortable and safe, the chances are great that it was Sundeak. Classic Texture can be combined with Custom Scoreline, Masonry effects, Aggregate Effects, SunStamp, Tuscan and all other applications to enhance your project.

Benefits of choosing Sundeak Classic Texture:

- Slip-resistant coatings for your protection
- Cooler than concrete surfaces for your comfort
- Non-porous applications for ease of maintenance and care
- Unlimited designs and colors to fit your style and imagination
- A guarantee on the installation provided by Sundeak contractors



Sundek Products Needed

- **Sundek Additive.**
- **Sundek Premix**
- **Sundek Finish Coat**
- **Sundek Clear (optional)**

Product Description

Sundek Additive – A low solids acrylic binding polymer.

Sundek Premix – An acrylic base cement with medium grade sand.

Sundek Finish Coat – An acrylic water base low solids color dispersion.

Sundek Clear – An acrylic water base sealer (20% solids)

Application Instructions

Clean and etch concrete with a floor machine. Surface may also be diamond ground followed by pressure washing. Squeegee excess water and allow drying until there are no visible signs of water. Slab and ambient temperature above 40 ° and rising, staying above at least 4 hours. Apply a primer if needed. Perform all necessary repairs and install Sundek base coat. A second coat may be applied if required by substrate conditions. Detail and sand to smooth out base coat surface, then spray Sundek Classic Texture to surface. When completely dry, detail and scrape surface to remove any burrs or imperfections, in preparation for Finish Coat application. Spray Finish coat through out entire surface in one direction, after application has dried, apply second coat on opposite direction, (north-south, and then east-west). If requested, apply Sundek clear coat for extra protection.